

TM

# JINRONG WATCH

# INSTRUCTIONS

JR-199

## NOTICE


- Don't open the cover by yourself.
- This watch water-resist 3M(Vacuum Test), don't use the Burton when the watch in the water inside.
- If there is watch smoke or drips inside the watchcase, ask approved specialist to disassembly and repair at once, or the inner part's may damage caused by corrosion.
- Avoid being a strong vibration, electronic forms can be bearing common shock, such as gravity suffered the impact of brutal use of or fall in Gaine.
- Don't use it in strong electric field, static or high cycle environment.
- Don't use it in boiling or freezing environment.
- Rinse watch surface with soft cloth and clear watch, don't use chemicals, As the case, strap its own characteristics, combined with humidity and other climate. The table in use for some time after the appearance of colors may be subject to change (which belongs to the normal category).
- Prolonged use of colorful lights will consume large amounts of energy.
- When not in use this watch, please place it in a dry place.
- Please read this instruction carefully before using this watch.
- Product function and appearance in order to prevail in kind

## FUNCTION AND SPECIFICATION

- Standard display: hour, minute, second, month, date and week.
- 12/24hour
- LED colorful lights
- Stopwatch stage (backkeeping function)
- Alarm and hourly chime function
- Snooze function
- Use temperature: 5°C-35°C
- Degree of accuracy: at normal temperature: descend one month
- Battery: CR2016 3V
- Life of battery: able to supply power for 18 months under the following situation.
- Power function per day
- one 11 function per day
- one alarm operation per day

(1)

## OPERATION



### Normal display sketch map


- Button explain**
  - A (MODE) --- Function selector button
  - B (LIGHT/SET) --- LED Light
  - C (ADJUST) --- can change every digit button

### HOW TO USE LIGHT

In any display mode press B button lit LED Lights, Press and hold down the colored lights can be continuously synchronized out put


### HOW TO CHANGE 12/24 FORMAT

In normal display press C button.




(2)

### HOW TO SET ALARM





when minute flash press C can when hour flash and alarm on adjust minute.

### HOW TO ON/OFF THE ALARM AND HOURLY CHIME




(3)

### HOW TO USE THE CHRONOGRAPH



(4)

### HOW TO SET TIME, WEEK AND DATE



### CAUTIONED

As the company continues to optimize the product and continuously improve product quality, product features may be slightly subject to change without notice.

On the use of this product may cause a third party for any losses and any compensation, the company no responsibility.

MANUFACTURERS: SHENZHEN YAOJINRONG TECHNOLOGY CO., LTD  
 ADDRESS: RELIANCE SCIENCE PARK, BAY LUN, SHENZHEN, GUANGDONG, CHINA  
 TEL: 0086-0755-29563663 FAX: 0086-0755-29563663  
 Http://www.jinrong.cn, alibaba.com/

(5)