



## INSTRUCTIONS

- Don't open the cover by yourself.
- This watch is water-resistant (30m/waterproof) → don't use the button when the watch is in the water inside.
- If there is a water smudge or salt inside the watchcase → approved specialist to de-salt and repair or care of the rear parts may damage caused by corrosion.
- Avoid being a strong vibration → electronic forms can be bearing common shock, such as greatly reduced the impact of motor vehicle or fall in case.
- Don't use it in boiling or freezing environment.
- Remove watch surface with soft cloth and clean watch with alcohol swab. As the case → strap its own characteristics, combined with humidity and other create the table in its own environment. The appearance of colour may be subject to change (which belong to the normal category).
- Prolonged use of colour light will consume large amounts of energy.
- When not in use, this watch please place it in a dry place.
- Please read this instruction carefully before using this watch.

Product function and accessories in order to read in manual.

- Standard display: hour, minute, second, month, date and week
- LCD show
- LED colorful lightings
- Stopwatch stage timekeeping function
- Alarm and hourly chime function
- Use temperature 3°C~35°C
- Degree of accuracy at normal temperature within second one month
- Battery: CR2016 3V
- Life of battery : Able to supply power for 18 months under the following situation
  - One illumination per day
  - One alarm operation per day

 Function selector button
  LED Light

 Digital call key
  Call On/Off And GSM Format Key And Start/End

 Call On/Off And GSM Format Key And Start/End
  Call On/Off And GSM Format Key And Start/End

In any display model press & button-LED light.  
Press and hold-down the colored light can be continuously synchronized output

Diagram illustrating the normal display and the time and mode display of the watch.

**NORMAL DISPLAY**  
(TIME ADJUSTMENT)

**Time and Mode Display**

In the time and mode display, the hour follows:

- A: Hour
- B: Minute
- C: Second

In normal time display mode press C don't release, then press C to ON/OFF item

Digit 1 can flash, then press & count up, then press C to turn to 2nd.

In any display model press D button can adjust the text display

**敬告**

○ 当前市场可买可不买放心产品，不购买放心产品，产品一旦出问题就难善其后，都对不起消费者。

○ 万能牌热水器产品被媒体广泛质疑和批评三方有目共睹，希望可买可不买的产品，

新地址：扬州市五洲电器股份有限公司  
公司地址：中国江苏省扬州市江都镇江都镇第一居委会1-102  
电话：(0525)25665863 传真：(0525)25665863  
http://www.jiutian.com.cn/