



JIN RONG WATCH

I  
N  
S  
T  
R  
U  
C  
T  
I  
O  
N  
S


**NOTICE**

- Don't open the cover by yourself.
- This watch water-resist (30m/3atm) but I don't use the button when the watch is in the water.
- If there is some scratch or crack inside the watchcase, ask professional specialist to disassemble and repair or contact the store where the product is sold by ourselves.
- Avoid being a strong vibration, electronic items can be damaged and broken, such as directly address the impact of mobile cell and etc.
- Don't use it in floating or freezing environment.
- Some watch function may not work that does watch don't use chronograph as the case - stop to use chronograph continued and function when you change the date to save time after the appearance of color may be subject to change - which belong to the normal category.
- Prolonged use of color lights will consume large amounts of battery.
- When not in use this watch please place it in a dry place.
- Please read this instruction carefully before using the watch.
- Product function and appearance is under approval to test.

**FUNCTIONAL SPECIFICATIONS**

- Material: stainless steel, ceramic, leather, metal, leather, metal
- 100meters
- LED color display
- Resistant to high temperature
- Resistant to water pressure
- Brown leather
- Low temperature: -20°C
- Stop use of chronograph or normal temperature will not work properly
- 100% water-resist
- LED display - which is easily clean for the function when the battery is empty
- One function per day
- One year warranty service

**OPERATION**




**Button explain**

- **L** Light
- **D** Date
- **C** Crown
- **S** Stop


**HOW TO USE LIGHT**

In any display function press the button several times. Press and hold down the crown button for continuously illuminated light.


**HOW TO CHANGE 12/24 FORMAT**




**HOW TO CHECK DATE**




**HOW TO DISPLAY THE ALARM TIME**




**HOW TO SET DATE**




**HOW TO ON/OFF ALARM**




**HOW TO ON/OFF HOURLY CHIME**



**HOW TO USE THE CHRONOGRAPH**



**HOW TO SET TIME, DATE, WEEK**



**CAUTIONED**

- Please do not use the watch in the water.
- Do not use the watch in the water.
- Please do not use the watch in the water.