JIN RIONG WATCH

INSTRUCTIONS

NOTICE

- Don't open the cover by yourself.
- This watch water-resist 3m(vacuum test) don't use the button when the watch in the water inside.
- If there is water smoke or drips inside the watchcase , ask approved specialist to dis-assembly and repair at once,or the inner parts may damage caused by corrosion.
- Avoid being a strong vibration , electronic forms can be bearing common shock , such as gravity suffered the impact of brutal use of or fall in calm.
- Don't use it in broiling or freezing environment.
- Rinne watch surface with soft cloth and clear watch ,don't use chemicals.As the case , strap its own characteristics,combined with humidity and other climate the table in use for some time after the appearance of colors may be subject to change （which belong to the normal category ）
- Prolonged use of colorful lights will consume large amounts of energy
- When not in use this watch,please place it in a dry place.
- Please read this instruction carefully before using this watc
- Product function and appearance in order to prevail in kind

FUNCTION AND SPECIFICATION

- Standard display ： hour、minute、second、month、date and week.
- 12/24 hour
- LED colorful lightsings
- Stopwatch stage timekeeping function
- Alarm and hourly chime function
- Snooze function
- Use temperature 5℃-35℃
- Degree of accuracy at normal temperature ±60 second one month
- Battery ： CR2016 3V
- Life of battery ： 40hr to supply power for 16 months under the following situation
- One-hundred-open-day
- One alarm operation per day

OPERATION



Normal display sketch map

Button explain

A (LIGHT) ---- Function selection button　　B (MODE) ---- Led Light

C (START) ---- Digital carry key　　D (SET) ---- can change every digit button

HOW TO USE LIGHT

In any display mode,press A button tolights.
Press and hold down the colored lights can be continuously synchronized output.

HOW TO CHANGE 12/24 FORMAT



HOW TO CHECK DATE

You can check the date if you hold down the-D-button in normal display.

HOW TO DISPALY THE ALARM TIME

In normal time display mode press C don't release you can see the alarm time.



HOW SET THE ALARM TIME



ADJUST WHAT DO YOU NEED THEN PRESS A RETURN NORMAL TIME

HOW TO ON/OFF ALARM

In normal time display mode press C two 「tr ehtear」 then press C to ON/OFF Alarm

HOW TO ON/OFF HOURLY CHIME

In normal time display mode,press C two 「tr ehtear」 then press A to ON/OFF hourly chime

HOW TO USE THE CHRONOGAPH



HOW TO SET TIME,DATE,WEEK



CAUTIONED

- As the company continues to optimize the produced,and continuously improve product quality, product features may be slightly subject to change without notice.
- On the use of this product may cause a third party for any losses and any co-prosecution,the company no responsibility.

MANUFACTURERS: SHENZHEN YUCHUANGRONG TECHNOLOGY CO.,LTD
Address: 6/5/F Room 604 Floor Tian'Ji Building No 1 Hezheng west Road Baoan District ShenZhen City, Guangdong 518036 China
TEL: 0086-0755-29592923　　FAX:0086-0755-29592922
WEB: www.jinrongwatch.com