


# iTouch Wordtime Watch(世界时间触摸表)


## OPERATION 操作指南

- Two ways operation  
两种操作方式 (A, B键)
- 35Citys word time  
世界时间 (35城市)
- stopwatch and timekeep  
秒表功能
- Tmr function  
倒计时功能
- 6 groups clock set  
6组闹铃
- EL backlight  
带月光模式




After touch 3 seconds then loosen your finger, and then touch quick change format

触摸三秒松开手再短时间触摸各模式间循环切换




## HOW TO USE THE CHRONOGRAPH


### 1. Normal time set 设置正常时间



### 2. Alm set 设置闹铃时间



### 3. STW SET 设置跑秒



### 4. TMR SET like above. 设置倒计时 (操作同上, 短按4次, 进放TMR设置。)

Attention: after 5 seconds no operation will default set currently. after 10 seconds will fix button